

ATTENTION

Using a Topper Rack™ with top slot style load bars

Fits load bars from VW, Audi, Mercedes, Thule Rapid Aero (20 mm slot), BMW, Mini (25 mm slot), and Saris

The installation of the enclosed mounting hardware is different from what is shown in the installation manual for your Topper Rack. Start by inserting the head of the carriage bolt in the slot on the bottom of the Topper beam. Loosely attach the enclosed bracket to the beam by placing the hole at the point of the bracket over the bolt and loosely attach it with the nut and washer. Next place Atoc's special mounting bolts in the slot of your load bars with the threaded end pointing upward. Place your Topper over the bolts, then place the washers and nuts on top of the Topper's mounting brackets and firmly tighten all nuts per the Topper's installation manual.